



MULTIQUOTE POSITIONNER PQ10





PQ10 is a multiaxis positionner that allows to independently control the mobile elements of the bending machine on which it is insert.

The use of its various applications is easier thanks to PQ10 touch-screen functioning and its operating system Microsoft Windows[®] CE.

Its main functions are:

- □ Single axes positioning, given by the setting of the required quote on the main page and by turning on the axes actuator.
- □ Sequential axes multi-positioning, that can be used to move different axis in succession, up to the desired quotes, thanks to the setting from the page shown below:



 NumeroCode
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0

Posicionanento a cero

Pic.: a) Multi positioning execution





The user can rotate the machine scheme by 180° in any time, so as to adjust the positioner visualization to the user's needs.

PQ10 is provided with an advanced analysis system useful to diagnose problem and/or maintenance that may occur in the command circuit. In case you need it, an alarm window will appear with the description of the problem and a picture of the particular point on which operate.

Some technical data of the positioner include:

- □ USB 2.0 connexion on the inferior side of the screen;
- □ display LCD 12" (800x600 resolution);
- □ high precision and sensitivity touch-screen.